



Assembly Instruction / Instruction D'assemblage 1100 JO

Installation Instruction:

- A- Insert the joining coupling between the two sections or fittings.
- B- Pass the carriage bolts [1] through the joining coupling and the section, then install the flange nylon lock nut [2].
- C- Make sure to tight every nut properly.

Instruction pour l'Installation:

- A- Installer le joint d'union entre les deux sections désirées.
- B- Passer les boulons de carrosserie [1] à travers le joint d'union et le corps de la section puis installer l'écrou à garniture de nylon [2].
- C- Assurez-vous de bien serrer tous les écrous.

